



## **Lancer 5% Handling Instructions**

1. Always wear chemical resistant clothing and gloves when handling Lancer 5% (PAA).
2. Always wear chemical resistant goggles when handling Lancer 5%.
3. Never un-couple a Lancer 5% Cornelius Keg from the dispensing cart when there is pressure left in the keg. Turn off the gas valve on the nitrogen tank before un-coupling a Lancer 5% Cornelius Keg. Relieve all pressure in the Cornelius Keg by pulling the ring on the pressure relief valve. Take care not to stand directly above the keg while coupling, un-coupling or relieving pressure.
4. Do not contaminate the top of the Cornelius Kegs. Keep the kegs sanitary at all times. Contamination with soil, grease, oil, metal and other components is un-acceptable and could lead to product contamination and systems failure.
5. Never open the man-way cover to the Cornelius Keg. This can allow contamination of the product, heat generation, high pressure loss of product and potential bodily injury.
6. Never apply more than 20 pounds of pressure to the Cornelius Keg. Higher pressures can cause an increased risk of bodily injury. Never leave the gas cylinder valve open. To pressurize a keg crack the cylinder to apply pressure to the keg and then close the valve. Never stand directly in front of the cart when performing this action. When flow from the Lancer 5% discharge line slows, repeat the above process. Do not attempt to adjust the gas regulator. The gas regulator is set by Heritage Systems and should never be adjusted by winery personnel. Call Heritage Systems for service.
7. If leaks are present in the Cornelius Keg and/or the dispensing cart shut off the gas supply, relieve the pressure on the keg and drain the remaining Lancer 5% from the discharge line by opening the discharge valve while directing flow into a suitable container. Drain the container into a winery process water drain and flush with water. Secure the equipment in a contained area and call Heritage Systems for service. Do not attempt to repair or use equipment that is in need of repair.
8. Follow all handling, safety and precautionary instructions on the Lancer 5% material safety data sheet and the Lancer 5% label located on the Cornelius Keg.
9. Follow all application, handling and safety procedures outlined and implemented by your winery management team.

I acknowledge receipt of this information and have been informed of the procedures for safe handling and use of this product. User assumes all risk associated with the use of this product and equipment.

\_\_\_\_\_  
Name

\_\_\_\_\_  
Signature

\_\_\_\_\_  
Date